



**Action:** Sand repair area.  
**Use:** P320 Disc.  
**Action:** De-grease and tack repair area.



**Action:** Apply Dry Guide Coat to primed area.  
**Use:** Mirka Dry Powder Guide Coat.



**Action:** Sand primed area.  
**Use:** Mirka Abranet P320 Strip.



**Action:** Re-apply Mirka Dry Guide Coat and machine sand primer.  
**Use:** P500 disc with interface pad.



**Action:** Blend area by machine.  
**Use:** Mirka Abralon 1000 77mm Disc.



**Action:** Expand blend area further.  
**Use:** Mirka Abralon 2000 77mm Disc.