



1

**Action:** De-nib surface.  
**Use:** Mirka® DEROS 325CV with P1500/P2000 Microstar (dry) or Mirka® AOS-B 130NV with P1500/P2000 WPF discs (with soapy water).

WIPE CLEAN



2

**Action:** Further reduce scratch pattern.  
**Use:** Mirka® DEROS 325CV Abralon® J3 3000 disc and soapy water.

WIPE CLEAN



3

**Action:** Apply compound to surface of lambswool pad and polish until scratches have been removed.  
**Use:** Mirka® PS1437 with Polarshine® 10 with Lambswool Pro polishing pad

WIPE CLEAN



4

**Action:** Apply compound to yellow waffle polishing pad to further improve gloss level.  
**Use:** Mirka® PS1437 with Polarshine® 10 with Mirka yellow waffle pad

WIPE CLEAN



1

**Action:** Sand large defected area  
**Use:** Mirka® DEROS 625CV with Microstar® P1200 followed by P1500.

WIPE CLEAN



2

**Action:** Further reduce scratch pattern.  
**Use:** Mirka® DEROS 625CV with Abralon® J3 3000 disc.

WIPE CLEAN



5

**Action:** Remove holograms and clean off any residue.  
**Use:** Mirka® PS1437 with Mirka black waffle pad and Polarshine® 5 and Mirka yellow microfibre cloth.